

TROUBLESHOOTING GUIDE

1. POWER UP APOLLO

- a. Plug a battery into the primary battery port (nearest USB)
- b. Apollo turns on (LED flashes)

IF APOLLO DOES NOT TURN ON

1. Charge the primary battery

2. SYNC THE REMOTE

- a. Plug in USB dongle
- b. Wait 10 seconds
- c. Unplug the USB dongle
- d. Plug in the remote
- e. Wait 10 seconds
- f. Plug in USB dongle

*For additional information, please refer to the Apollo Quick Start Guide

3. LINK WITH ROBOT

- a. Press the PS button on the remote
- b. Lights on remote will flash
- c. Remote will vibrate

IF LIGHTS ON THE REMOTE DO NOT FLASH

1. Charge the remote battery

IF A CONNECTION IS MADE BUT IMMEDIATELY LOST

1. Try again
2. Press the PS button
3. Charge the primary battery

4. CONTROL MOTORS

- a. Plug a battery into the motor battery port
- b. Insert a motor into the M1 motor port
- c. Move the joystick to drive the motor

IF THE MOTOR DOES NOT TURN AS EXPECTED

1. Check that the motor is a 3-wire motor or motor controller
2. Try motor port M2
3. Charge the motor battery

